

BLANCO






Reparatur-Anleitung
Repair instruction

BLANCO SAGA HD



BLANCO

BLANCO SAGA




Art.-No. 511 324

⬡ 22 mm




⬡ 3 mm

Art.-No. 139 188





⬡ 2 mm

Art.-No. 139 189




⬡ 2 mm


Art.-No. 139 189




10 mm





10 mm





10 mm




10 mm



2 mm
Art.-No. 139 189



2 mm
Art.-No. 139 189





23




3 mm

Art.-No. 139 188



24



25




Art.-No. 511 324

22 mm






26



27



BLANCO

BLANCO SAGA




Art.-No. 511 324

22 mm





3 mm

Art.-No. 139 188





2 mm

Art.-No. 139 189




2 mm






Art.-No. 139 189




10 mm



10 mm




10 mm



23

10 mm




24



25

2 mm

Art.-No. 139 189



26



27

2 mm


Art.-No. 139 189



28



29




30

3 mm

Art.-No. 139 188



31




32

Art.-No. 511 324


22 mm



33



34



Art.-No. 511 324

22 mm

